


QCY-T17 TWS Bluetooth Headset User Guide

[Home](#) » [QCY](#) » QCY-T17 TWS Bluetooth Headset User Guide



QCY-T1 7
TWS Bluetooth headset
Model: BH21Q17A



<https://mapp.qcymall.com/qcyearphones/zh/download/qcy>

For a better user experience, please scan to download the QCY app before start-up.


Contents [[hide](#)]

- [1 Overview](#)
- [2 How to Connect](#)
- [3 Factory Setting](#)
- [4 Use Instruction](#)
- [5 Function](#)
- [6 Warranty Card](#)
- [7 FCC Statement](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

Overview

Choose Eartips

Please try medium eartips first as they fit most people.



The above pictures are for reference only and practical items may vary.


How to Connect

First Time Pairing:

1. Pick up both earbuds, pop them back in case then close the lid to activate them.
2. Pick them up again
3. On a cellphone, search for QCY-T17 and tap to connect. " Pick up earbuds to power on them. Otherwise, please charge the case and try again.


Switch Paired Device:

1. Turn off the phone's Bluetooth faculty and earbuds will auto disconnect and turn connectable.
2. On phones, search for QCY-T17 and tap to connect.
 - * Multi-point connection is not available. Earbuds will auto-reconnect to the phone upon powering up again.



Factory Setting

Push earbuds into the case, open lid, and keep touching earbuds for 10s or until LED blinks white 5 times to reset and power on earbuds.




LED for Battery Level

Battery level >50%: blue

Battery level <50%: red


Use Instruction



LED on Case

LED will blink blue when the case is charging and turn solid blue once it is topped up.

Function





Power-on: pick up earbuds to power on them

Power-off: push earbuds into the case and close lid



Answer/end call: double touch panel



Ignore call: keep touching panel for 1.5s



Skip track backward: keep the touching left panel



Skip track forward: keep touching the right panel



Voice assistant: triple touch left panel



Playback/pause: double touch the left/right panel to play/pause



Low-latency mode: triple touch right panel



Warranty Card

Warranty Period

12 months after you purchase this item for you may inquire your local shopper for more details).

Free Service:

Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service.

Model Number:_____

Date of Purchasing:_____

Users Name:_____

Users Phone:_____

Users Address:_____

Shop's Name:_____

Shop's Address:_____

Comments:_____

Free exchange service will not be accessed under the following” circumstances:

1. Damages caused unauthorized disassembly.
2. Defects or physical damages caused by leaking or dropping off.
3. Damages by an act of God. Supposing your item is within any damages or defects except the above circumstances, return to us or your distributor for free repairing.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

–Reorient or relocate the receiving antenna.

–Increase the separation between the equipment and receiver.

–Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

–Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's

authority to operate the equipment.

Hazardous substances and their contents in the item

Part Name	Hazardous Substances									
	Pb	Hg	Cd	Cr) Ni	PBB	PBDE	DIBP	DEHP	DBP	BBP
Main box						0				
Battery	0	0	0	0	0	0	0	0	0	0
Ear tips	0	0	0	0	0	0	0	0	0	0
Accessories	0	0	0	0	0	0	0	0	0	0
Charging cable	X	0	0	0	0	0	0	0	0	0

This form is made by SJ/T 1364 regulation.

O: means that hazardous substance content in the homogeneous materials of this part is within the limits of (EU) 2015/863 regulation.

X: means that hazardous substance content in, at least, one certain homogeneous material of this part is beyond the limits of (EU) 2015/863 regulation, but there is no mature alternative in the industry at present, it still conforms to the EU ROHS Directive in the scope of the exemption.

Notes: Please arrange using time properly as your hearing may be damaged by using the device for a long time. Manufacturer: Dongguan Hele Electronics Co., Ltd. Address: Daojiao Town, Dongguan City, Guangdong, China



Tips

1. Before using the earbuds, please read the manual carefully and keep it for future references.
2. The earbuds need to be fully charged prior to first-time use.
3. If the earbuds are left unused for over two weeks, please recharge
4. Please use the chargers made by a qualified manufacturer.
5. If the earbuds cannot be found by your phone, please check whether they are in pairing mode; if left unconnected for a long while the earbuds will exit pairing mode, please re-enter the mode; if a procedure error of your phone occurs reboot it; if a procedure error of the earbuds occurs, reboot or reset it.

Caveats

1. Never disassemble or modify your earbuds for any reason to avoid any damages and danger.
2. Do not store the earbuds in extreme temperatures (under 0°C or over 45°C).
3. Avoid using the indicator close to the eyes of children or animals.
4. Do not use the earbuds during a thunderstorm to avoid dysfunction and increased risk of electricshock.
5. Do not use harsh chemicals or strong detergents to clean the earbuds.

Note: please do not use earbuds for a long time as may damage your hearing.

	QCY QCY-T17 TWS Bluetooth Headset [pdf] User Guide BH21Q17AR, RDR-BH21Q17AR, RDRBH21Q17AR, BH21Q17AL, RDR-BH21Q17AL, RDRBH 21Q17AL, QCY-T17 TWS Bluetooth Headset, TWS Bluetooth Headset
--	--

Related Posts



[TWS Bluetooth Earbuds QCY-15 User Manual](#)

TWS Bluetooth Earbuds QCY-15



[QCY TWS Bluetooth Earbuds QCY-T5 Pro User Manual](#)

QCY TWS Bluetooth Earbuds QCY-T5 Pro User Manual Overview How to
Pair Factory Setting How to Wear Mono...



[Gelius AIR TWS Headset User Manual](#)

Gelius AIR TWS Headset User Manual Gelius AIR TWS Headset User
Manual - Optimized PDF Gelius AIR TWS...



[Motorola HK250 Bluetooth Headset User Manual](#)

Motorola HK250 Bluetooth Headset User Manual - Download
[optimized]Motorola HK250 Bluetooth Headset User Manual - Download